

## **FITTING INSTRUCTIONS FOR A TWO PIECE FLAT CANOPY**

If fixing to Frog Hall Bricks, ensure you fix through the solid part of the Brick.

- 1- Establish and mark a centre line & desired height on the Wall
- 2 - Mark a centre line on the Entrance Canopy Soffit.
- 3 - Ensure the mounting surface is plumb and smooth.
- 4 - Offer the **Canopy Soffit Only** to the wall and line up the Centre Lines.
- 5 - With the Canopy Soffit held in position, drill a 6.5mm x 100mm hole **tight to one side** of the Soffit through the **(back vertical upstand)** in to the brick wall.  
Fix using 100mm x 7.5 mm Concrete Fixing and oversize mudguard washer.
- 6 - Drill a 6.5mm x 100mm hole through the other side of the canopy soffit **tight to the side**.  
Then fix using 100mm x 7.5 mm Concrete Fixing & Mudguard Washer.  
**The Fixings are to be tight to each end of the canopy & 2 high (80mm apart).**
- 7 - **Check the canopy is level/plumb, on length and projection by using a spirit level.**  
**(pack using plastic frame packers, tighten and slacken the fixings, were required).**
- 8 - Now drill & fix the canopy soffit **tight to each Internal Baffle** through the **(back vertical upstand)**.  
**(The fixings need to be 2 high & 80mm apart).**  
**(2 fixings to one side of the baffle and 2 fixings to the other side, (repeat this to each baffle).**
- 8a – **Again Check the canopy is level/plumb, on length and projection by using a spirit level.**  
**(pack using plastic frame packers, tighten and slacken the fixings, were required).**
- 9 – If installing Decorative Legs, pre drill the flat section at the end of each leg  
**(Only pre drill side going against the wall)**
- 10 – Hold the Decorative Leg up to the canopy soffit; drill a 6.5mm hole through the leg in to the wall and fix using 100mm concrete screw together with a washer to take a cap to cover the fixing.
- 11 – Screw down through the canopy soffit in to the leg using a 30mm wood screw.
- 12 – Offer the roof to the soffit with Bigheads running through the pre drilled holes.
  - **Drill through the roofs integral flash/upstand into the wall and place 7.5mm x 100mm R A Concrete Fixing together with a plastic washer.**  
**(The washers are to receive caps to cover fixings)**
  - **Before taking the fixing tight to the wall, you may have to pack out between the flange/flash and the wall to avoid twisting the Canopy.**
  - **Fixings to be tight to both ends of the roof flash and at least every 400mm centres.**  
**(The fixings need to be equally spread out at the same height)**
- 13 - Cover all visible screw heads with appropriate coloured screw caps.
- 14 - You can also lead over the flange into the brickwork, completely optional.
- 15 – Mastic Seal the flash to the wall in Clear and the soffit/fascia in the appropriate colour
- 16 – Your Canopy is Maintenance Free; we recommend regular cleaning with Soap & Water.