

## Fitting Instructions for The Boughton

### Apex 2-piece Canopy

#### STEP 1

A: Mark centre-line onto door frame.

B: Mark spirit level line – do not cover any weep holes.

#### STEP 2

C: Mark centre-line on canopy soffit.

D: 1<sup>st</sup> operative to offer soffit to wall marrying up all marks.

#### STEP 3

E: 2<sup>nd</sup> operative to drill 6.5x120mm tight to both ends (central) Fix using 7.5x100mm concrete fixing with oversize mudguard washer.

#### STEP 4

F: Use spirit level to check canopy is level on projection.

G: Pack between back of canopy and wall where required. Tighten/slacken fixing if necessary.

#### STEP 5

H: Once canopy is all level, put fixings along rest of back into wall at max 400mm (equal spacing) I:

Use spirit level to double check (loosen & pack if necessary)

## STEP 6

J: Mark and pre-drill roof part of canopy along back flange at max. 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

## STEP 7

K: Offer roof to soffit – pin fasteners to meet holes in soffit.

L: Drill (6.5x120mm bit) through pre-drilled holes (J) and into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive caps.

## STEP 8

M: Before fixing tight, packers may be necessary between roof flange and brickwork to prevent canopy going out of level.

N: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

O: Cover all visible screw heads with colour matching caps or lead flash into brickwork and over flange (optional).



the  
**canopyshop**

**Tel:** 01536 446393 **Email:** [sales@thecanopyshop.co.uk](mailto:sales@thecanopyshop.co.uk) **Web:** [www.thecanopyshop.co.uk](http://www.thecanopyshop.co.uk)

6 Canberra House, Corbygate Business Park, Corby, NN17 5JG