



## **Fitting Instructions for The High-Profile Cherwell and Sandringham 2-piece High Profile Flat Canopy**

### **STEP 1**

- A: Mark centre-line onto door frame.
- B: Mark spirit level line – do not cover any weep holes.

### **STEP 2**

- C: Mark centre-line on canopy soffit.
- D: 1<sup>st</sup> operative to offer soffit to wall marrying up with marks.

### **STEP 3**

- E: 2<sup>nd</sup> operative to drill 6.5x120mm tight to both ends (central)
- F: Fix using 7.5x100mm concrete fixing with oversize mudguard washer.

### **STEP 4**

- G: Use spirit level to check canopy is level on projection.
- H: Pack between back of canopy and wall where required. Tighten/slacken fixing if necessary.

### **STEP 5**

- I: Once canopy is all level, put 3 fixings (1 into each brick course) adjacent to all baffles and at both ends of canopy.
  - J: Use spirit level to double check (loosen & pack if necessary)
- (please note if fixing to Frog Hall Brick ensure fixing goes into solid part of brickwork)



Tel: 01536 446393 Email: [sales@thecanopyshop.co.uk](mailto:sales@thecanopyshop.co.uk) Web: [www.thecanopyshop.co.uk](http://www.thecanopyshop.co.uk)

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX

## STEP 6

K: Mark and pre-drill roof part of canopy along back flange at 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

## STEP 7

L: Offer roof to soffit – pin fasteners in roof to meet holes in soffit.

M: Drill (6.5x120mm bit) through pre-drilled holes (K) and into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive caps.

## STEP 8

N: Before fixing tight, packers may be necessary between roof flange and brickwork to prevent canopy going out of level.

O: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

P: Cover all visible screw heads with colour matching caps, or lead flash into brickwork and over flange (optional).



the  
**canopyshop**

Tel: 01536 446393 Email: [sales@thecanopyshop.co.uk](mailto:sales@thecanopyshop.co.uk) Web: [www.thecanopyshop.co.uk](http://www.thecanopyshop.co.uk)

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX