

Fitting Instructions for The New Lerwick & Eaton

Mono- Pitch Canopy with Brackets

STEP 1

- A: Mark centre-line over door frame.
- B: Mark spirit level line <u>do not</u> cover any weep holes.

STEP 2

C: Mark centre-line on canopy soffit.

D: 1st operative to offer soffit to wall marrying up with marks.

STEP 3

E: 2nd operative to drill 6.5x120mm tight to both ends (central) Fix using 7.5x100mm concrete fixing. Ensure fixing into most solid part of wall/brickwork.

STEP 4

F: Use spirit level to check canopy is level on projection.

G: Pack between back of canopy and wall if/where required. Tighten/slacken fixing if necessary.

STEP 5

H: Once canopy is all level, put fixings adjacent to all baffles and along back lower soffit at max 300mm c/c.

I: Use spirit level to double check (loosen & pack if necessary)



Tel: 01536 446393 Email: sales@thecanopyshop.co.uk Web: www.thecanopyshop.co.uk Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX

STEP 6

J: Bracket to be drilled in centre of flat part at both ends.

K: Offer to correct position (top of edge of bracket to be under soffit) and mark on the wall through pre-drilled holes.

L: With bracket removed drill into brickwork, then fix using 100mm concrete screws, with washer to take cover caps.

M: Fix bracket up to canopy using 70mm wood screws with washer for cover caps. (Repeat for both brackets)

STEP 7

N: Mark and pre-drill roof of canopy along back of flange at max 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

O: Offer roof to soffit – roof lip to overlap with soffit lip edges.

P: Drill (6.5x120xx bit) through pre-drilled holes into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive colour match caps.

STEP 8

Q: Before fixing tight, packers may be necessary between roof flange and brickwork to prevent canopy going out of level.

R: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

S: Cover all visible screw heads with colour matching caps, or lead flash into brickwork and over flange (optional).





Tel: 01536 446393 Email: sales@thecanopyshop.co.uk Web: www.thecanopyshop.co.uk Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX