



**Fitting Instructions for The Strauss, Temple, Bovey, Barlow, Elite, Willington,
Calcot, Clifton & Adlington**

1-piece Pitched Canopy with Brackets

STEP 1

A: Mark centre-line onto door frame.

B: Mark spirit level line – do not cover any weep holes.

STEP 2

C: Mark centre-line on canopy soffit.

D: 1st operative to offer soffit to wall marrying up with marks.

STEP 3

E: 2nd operative to drill 6.5x120mm to each side through flange.

F: Fix using 7.5x100mm concrete fixing with washer to take cover caps.

STEP 4

G: Use spirit level to check canopy is level on projection.

H: Pack between back of canopy and wall where required. Tighten/slacken fixing if necessary.

STEP 5

I: Once canopy is all level, put fixings along the rest of flange at max 400mm (equal spacing).

J: Use spirit level to double check (loosen & pack if necessary)

(please note if fixing to Frog Hall Brick ensure fixing goes into solid part of brickwork)



Tel: 01536 446393 **Email:** sales@thecanopyshop.co.uk **Web:** www.thecanopyshop.co.uk

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX

STEP 6

K: Brackets (if using) to be drilled in centre of flat part of the leg/bracket at both ends.

STEP 7

L: Offer bracket to desired position, mark on the wall and underside of canopy through pre-drilled holes.

M: With brackets removed drill into brickwork, then fix using 100mm concrete screws, with washer to take cover caps.

N: Fix bracket up to canopy using 70mm wood screws with washer for cover caps.

STEP 8

O: Silicone mastic seal roof flange/wall and soffit/brickwork in appropriate colour.

P: Cover all visible screw heads with colour matching caps, or lead flash into brickwork and over flange (optional).



the
canopyshop

Tel: 01536 446393 **Email:** sales@thecanopyshop.co.uk **Web:** www.thecanopyshop.co.uk

Unit 13, Earlstrees Court, Earlstrees Industrial Estate, Corby, Northamptonshire, NN17 4AX