

Fitting instructions for the Stone Finish Door Surround

Step 1

- (A)** Measure inside width of Door Surrounds and, using a suitable pencil/marker, mark vertically onto the wall.
- (B)** Mark line for desired position of underside of Canopy. Ensure all markings are level & plumb (spirit level)

Step 2

- (C)** Fix, using 100mm Concrete fixings at max 600mm c/c, treated batten timbers (vertically) 2no onto the wall inside markings and 2no flush with the door reveal.

Step 3

- (D)** Fix treated batten timber (horizontally), using 100mm. Concrete fixings at max 600mm c/c, above the door reveal.

Step 4

- (E)** Hold Canopy to wall at the correct position - ensuring it is tight up against batten timber, central with door and level.
- (F)** Fix through roof upstand - 100mm Concrete screw fixings max 400mm c/c, with washers (for colour match caps)

Step 5

(G) Fix through underside of Canopy, into batten timber, using 50mm wood screws with washers (for colour matching caps)

(H) Measure & trim Door Surround to correct height & projection, to fit snug into door reveal & under canopy.

Step 6

(I) Use spirit level to check canopy is level on projection.

(J) Pack between back of canopy and wall if/where required. Tighten/slacken fixing if necessary.

Step 7

(K) Place Door Surround onto the timber battens. Double-check level & plumb using spirit-level, or follow the line of the brick-course / door frame.

(L) Fix through sides of the Surrounds, into the battens, using 50mm wood screws with washers (for colour matching caps)

Step 8

(M) Silicone mastic around the door surrounds & canopy to the wall and door frame using appropriate colour(s).

(N) Cover visible screw heads/washers with correct colour caps.



Tel: 01536 446393 **Email:** sales@thecanopyshop.co.uk **Web:** www.thecanopyshop.co.uk

6 Canberra House, Corbygate Business Park, Corby, NN17 5JG