

## Fitting instructions for the Door Surround and Apex Canopy

### Step 1

**(A)** Measure inside width of Door Surrounds and, using a suitable pencil/marker, mark vertically onto the wall.

**(B)** Mark line for desired position of underside of Canopy. Ensure all markings are level & plumb (spirit level)

### Step 2

**(C)** Fix, using 100mm Concrete fixings at max 600mm c/c, treated batten timbers (vertically) 2no onto the wall inside markings and 2no flush with the door reveal.

### Step 3

**(D)** Fix treated batten timber (horizontally), using 100mm. Concrete fixings at max 600mm c/c, above the door reveal.

### Step 4

**(E)** Hold Canopy to wall at the correct position - ensuring it is tight up against batten timber, central with door and level.

**(F)** Fix through roof upstand - 100mm Concrete screw fixings max 400mm c/c, with washers (for colour match caps)

## Step 5

**(G)** Fix through underside of Canopy, into batten timber, using 50mm wood screws with washers (for colour matching caps)

**(H)** Measure & trim Door Surround to correct height & projection, to fit snug into door reveal & under canopy.

## Step 6

**(I)** Use spirit level to check canopy is level on projection.

**(J)** Pack between back of canopy and wall if/where required. Tighten/slacken fixing if necessary.

## Step 7

**(K)** Place Door Surround onto the timber battens. Double-check level & plumb using spirit-level, or follow the line of the brick-course / door frame.

**(L)** Fix through sides of the Surrounds, into the battens, using 50mm wood screws with washers (for colour matching caps)

## Step 8

**(M)** Silicone mastic around the door surrounds & canopy to the wall and door frame using appropriate colour(s).

**(N)** Cover visible screw heads/washers with correct colour caps.



**Tel:** 01536 446393 **Email:** [sales@thecanopyshop.co.uk](mailto:sales@thecanopyshop.co.uk) **Web:** [www.thecanopyshop.co.uk](http://www.thecanopyshop.co.uk)

6 Canberra House, Corbygate Business Park, Corby, NN17 5JG