

## Fitting Instructions for Flat-back 2-piece Canopy & Door Surrounds

### Step 1

**(A)** Measure inside width of Door Surrounds and, using a suitable pencil/marker, mark vertically onto the wall.

**(B)** Mark line for desired position of underside of Canopy. Ensure all markings are level & plumb (spirit level)

### Step 2

**(C)** Fix, using 100mm Concrete fixings at max 600mm c/c, treated batten timbers (vertically) 2no onto the wall inside markings and 2no flush with the door reveal.

### Step 3

**(D)** Mark centre-line on canopy soffit.

**(E)** 1st operative to offer soffit to wall marrying up all marks.

### Step 4

**(F)** 2nd operative to drill 6.5x120mm tight to both ends (central) Fix using 7.5x100mm concrete fixing with oversize mudguard washer.

## Step 5

**(G)** Once canopy all level, put fixings adjacent to all baffles and at both ends of canopy.

**(H)** Use spirit level to double check (loosen & pack if necessary)

## Step 6

**(I)** Mark and pre-drill roof of canopy along back flange at max 600mm centres, using 6.5mm drill bit. Holes to be equally spaced and at same height.

**(J)** Offer roof to soffit - roof lip to overlap with soffit lip edges. Drill (6.5x120mm bit) through pre-drilled holes into brickwork. Fix using 7.5x100mm concrete fixing with washers to receive colour match caps.

## Step 7

**(K)** Place Door Surround onto the timber battens. Double-check level & plumb using spirit-level, or follow the line of the brick-course / door frame.

**(L)** Fix through sides of the Surrounds, into the battens, using 50mm wood screws with washers (for colour matching caps)

## Step 8

**(M)** Silicone mastic around the door surrounds & canopy to the wall and door frame using appropriate colour(s).

**(N)** Cover visible screw heads/washers with correct colour caps.



**Tel:** 01536 446393 **Email:** [sales@thecanopyshop.co.uk](mailto:sales@thecanopyshop.co.uk) **Web:** [www.thecanopyshop.co.uk](http://www.thecanopyshop.co.uk)

6 Canberra House, Corbygate Business Park, Corby, NN17 5JG